




571 58 076 opposite side support I = 40 mm Note: This part helps to spread out pressing forces to the whole width of the tool. If you perforate only right side of the sheet, place this part towards left side. And viceversa.






3x

571 58 061 perforating knife l = 80 mm 1x opposite side support (571 58 076) and 1x perforating knife 240 mm (571 58 059) are installed in the tool


Remaining 5 perforating knives come packed separately

2x



571 58 060 perforating knife l = 160 mm





571 58 059 perforating knife I = 240 mm



Tool comes with 240 mm perf knife and opposite side support installed.



Knives changed - 80 mm and 160 mm knives installed in this example.





Example of knife registration with respect to the graphics layout










Partial strike perforating tool in combination with 2x rotary perforating knives (AirSped 450 only)



To align knife and sheet position precisely you can also move side guides with sheets, instead of changing position of knives inside the tool.



